

# LA25

## Data Sheet



## Contents

Introduction .....	3
Safety instructions .....	3
Features .....	5
Options in general .....	5
Usage .....	5
Technical specifications .....	6
Special anodised housing .....	7
Speed and current curves .....	8
Current limits .....	10
Current cut-offs .....	10
Ordering example .....	11
Dimensions .....	14
Stroke tolerances .....	14
Built-in tolerances .....	14
Built-in dimensions .....	15
Piston rod eyes .....	19
Back fixtures .....	22
Back fixture orientation .....	24
Mounting of cables .....	25
Cable dimensions .....	26
Standard cable item numbers (included in new actuator) .....	26
Electrical installation .....	28
Environmental tests – Climatic .....	29
Environmental tests – Mechanical .....	31
Environmental tests - Electrical .....	32
Non-complying standards .....	33

## Introduction

Compact designed linear actuator ideal for narrow spaces. Comes with a high IP degree and aluminium housing and is suited to operate in almost any conditions.

With its robust design, high IP degree and aluminium housing, the actuator LA25 is ideal for harsh environments where operation under extreme conditions is required.

## Safety instructions

Please read this safety information carefully.

Be aware of the following three symbols throughout the document:



### **Warning!**

Failing to follow these instructions can cause accidents resulting in serious personal injury.



### **Recommendations**

Failing to follow these instructions can result in the actuator suffering damage or being ruined.



### **Additional information**

Usage tips or additional information that is important in connection with the use of the actuator.

Furthermore, ensure that all staff who are to connect, mount, or use the actuator are in possession of the necessary information and that they have access to this document.

Persons who do not have the necessary experience or knowledge of the product/products must not use the product/products. Besides, persons with reduced physical or mental abilities must not use the product/products, unless they are under surveillance or they have been thoroughly instructed in the use of the apparatus by a person who is responsible for the safety of these persons.

Moreover, children must be under surveillance to ensure that they do not play with the product.

### **Before you start mounting/dismounting, ensure that the following points are observed:**

- The actuator is not in operation.
- The actuator is free from loads that could be released during this work.

### **Before you put the actuator into operation, check the following:**

- The actuator is correctly mounted as indicated in the relevant user instructions.
- The equipment can be freely moved over the actuator's whole working area.
- The actuator is connected to a mains electricity supply/transformer with the correct voltage and which is dimensioned and adapted to the actuator in question.
- Ensure that the voltage applied matches to the voltage specified on the actuator label.
- Ensure that the connection bolts can withstand the wear.
- Ensure that the connection bolts are secured safely.

### **During operation, please be aware of the following:**

- Listen for unusual sounds and watch out for uneven running. Stop the actuator immediately if anything unusual is observed.
- Do not sideload the actuator.
- Only use the actuator within the specified working limits.
- Do not step on or kick the actuator.

### **When the equipment is not in use:**

- Switch off the mains supply in order to prevent unintentional operation.
- Check regularly for extraordinary wear.

### **Classification**

The equipment is not suitable for use in the presence of a flammable anaesthetic mixture with air or with oxygen or nitrous oxide.



### **Warnings**

- Do not sideload the actuator.
- When mounting the actuator in the application ensure that the bolts can withstand the wear and that they are secured safely.
- If irregularities are observed, the actuator must be replaced.



### **Recommendations**

- Do not place load on the actuator housing.
- Prevent impact or blows, or any other form of stress to the housing.
- Ensure that the cable cover is mounted correctly. Use 3.5 Nm torque.
- Ensure that the duty cycle and the usage temperatures for LA25 actuators are respected.
- Ensure that the cable cannot be squeezed, pulled or subjected to any other stress.
- Furthermore, it will be good practice to ensure that the actuator is fully retracted in the "normal" position. The reason is that there will be a vacuum inside the actuator if it is extended which over time can lead to water entering the actuator.

## Features

- 12 V/24 V DC permanent magnetic motor
- Load from 600 N - 2.500 N in push and pull
- Speed from 2.5 to 25 mm/seconds depending on load and spindle pitch
- Stroke length from 20 - 600 mm (Zero Point: 100 to 600 mm)
- Colour: Dark olive grey
- Protection class: IP66. Furthermore, the actuator can be washed down by a high pressure cleaner (IP69K static)
- Heavy-duty aluminium housing for harsh conditions
- Built-in endstop switches
- Mechanical endstop
- Guided nut
- Static safety factor: 2.0
- Noise level: Max. 58.5 dB(A) at nominal voltage and with no load, according to EN ISO 3743-1

## Options in general

- Safety nut in push or pull (2.500 N version: only safety nut in push; 600 N version: no safety nut)
- Exchangeable cables in different lengths up to 10 m
- Steel or stainless steel back fixture and piston rod eye
- Special anodised housing for extreme environments
- Analogue and digital feedback for precise positioning
- IC Basic and IC Advanced
- I/O Basic, I/O Customised and I/O Full
- Limit switch principle
- Zero point principle
- CAN bus J1939
- CANopen
- LIN bus
- IO-Link
- Actuator Connect™ and BusLink
- IECEx/ATEX certified for Zone 21

## Usage

- Duty cycle is max. 20% (4 min. drive and 16 min. rest)  
The duty cycles are valid for operation within an ambient temperature of +5°C to +40°C
- Ambient operating temperature: -40°C to +85°C (for IECEx/ATEX: T135 -25°C to +65°C; T125 -25°C to +55°C ), full performance from +5°C to +40°C
- Storage temperature: -55°C to +105°C

## Technical specifications

### 12 V

Type	Push/ Pull Max. (N)	Self-lock min. (N) Push/Pull				Spin- dle pitch (mm)	*Typical speed (mm/s)		Standard stroke length (mm)	*Typical amp. at 12 V		
		With short circuit		Without short circuit			No load	Full load		No load	Full load	
		Self- lock (N)	**Back- drive (mm)	Self- lock (N)	**Back- drive (mm)							
25030xxxxxxxxA...	2500	2500	1	2500	1	3	3.1	2.5	20-500	0.8	3.8	
25060xxxxxxxxA...	1500	1500	1	1500	2	6	6.6	5.2	20-600	0.8	3.8	
25090xxxxxxxxA...	1200	1200	2	1200	4	9	9.9	7.5	20-600	0.9	4.0	
25120xxxxxxxxA...	900	900	3	900	7	12	13	9.6	20-600	0.9	3.8	
25200xxxxxxxxA...	600	600	5	600	12	20	25	18	20-600	0.9	4.0	

### 24 V

Type	Push/ Pull Max. (N)	Self-lock min. (N) Push/Pull				Spin- dle pitch (mm)	*Typical speed (mm/s)		Standard stroke length (mm)	*Typical amp. at 24 V		
		With short circuit		Without short circuit			No load	Full load		No load	Full load	
		Self- lock (N)	**Back- drive (mm)	Self- lock (N)	**Back- drive (mm)							
25030xxxxxxxxB...	2500	2500	1	2500	1	3	3.2	2.6	20-500	0.4	1.9	
25060xxxxxxxxB...	1500	1500	1	1500	2	6	6.4	5.5	20-600	0.4	1.9	
25090xxxxxxxxB...	1200	1200	2	1200	4	9	9.5	8.1	20-600	0.4	2.0	
25120xxxxxxxxB...	900	900	3	900	7	12	12.6	10.4	20-600	0.4	1.9	
25200xxxxxxxxB...	600	600	5	600	12	20	25	18	20-600	0.4	2.0	

\* The typical values can have a variation of  $\pm 20\%$  on the current values and  $\pm 10\%$  on the speed values. Measurements are made with an actuator in connection with a stable power supply and an ambient temperature of 20°C.

\*\* The back drive is measured with a stable power supply at an ambient temperature of 20°C after 120 seconds of continuous push load.



Please note that all actuators featuring 'soft stop towards endstop' will run at a regulated speed, which is typically around 80% of the nominal speed.



## Special anodised housing

 This housing should be recommended for use in particularly harsh environments such as stables, where the actuator is in touch with extremely corrosive liquids and/or vapours such as ammoniac.

The anodised housing option embodies a special surface treatment of the aluminium housing in order to reduce corrosion of the housing and avoid any vapours or liquids entering the actuator. The anodised housing is also IP66/IP69K. This is only available in black.



## Speed and current curves

The charts below display typical values made with a stable power supply and an ambient temperature of 20°C.



## Speed and Current Curves

The charts below display typical values made with a stable power supply and an ambient temperature of 20° C.



## Current limits

Platform	Movement	12 V	24 V	Temperature
B, C, F	Outwards	8 A	5 A	Above
	Inwards	8 A	5 A	
<b>Reference temperature 0°C</b>				
Outwards	8 A	8 A	Below	
Inwards	8 A	8 A		

If the actuator's current consumption rises above the set limit, the actuator regulates and tries to keep it below the set current limit by reducing the PWM and therefore also the speed accordingly. The actuator does this continuously until the actuator stops moving (mechanically blocked) - something that is determined by monitoring the Hall feedback signal. If there are no changes to the Hall feedback signal during the set time frame, the Integrated Controller will cut power to the H-bridge motor circuit.

If the actuator is stopped due to the above-mentioned criteria, it automatically drives slightly in the opposite direction to reduce the torque in a blocking situation.

## Current cut-offs

The principle behind the current cut-off measurement is an 'above limit' and a 'below limit' accumulating counter. When the time-out counter reaches a specific value the current cut-off goes into effect. The time-out value is pre-set at 500 ms.

Platform	Movement	12 V	24 V	Temperature
3, 6	Outwards	8 A	5 A	Above
	Inwards	8 A	5 A	
<b>Reference temperature 0°C</b>				
Outwards	9 A	6 A	Below	
Inwards	9 A	6 A		

Platform	Movement	12 V	24 V	Temperature
7, 9	Outwards	15 A	10 A	Above
	Inwards	15 A	10 A	
<b>Reference temperature 0°C</b>				
Outwards	20 A	15 A	Below	
Inwards	20 A	15 A		

## Ordering example

**25 PPP XXX SS FF P M E I = B O R P C E F L P O XXX**

Type	<b>25</b>	= LA25
Spindle pitch	<b>PPP</b>	
	030	= 3 mm
	060	= 6 mm
	090	= 9 mm
	120	= 12 mm
	200	= 20 mm
Stroke length	<b>XXX</b>	= mm
Safety	<b>SS</b>	
	00	= None
	0A	= Safety nut
Feedback	<b>FF</b>	
	00	= None
	0K	= Single Hall
	0A	= Hall potentiometer (Analogue feedback)
	0F	= PWM
Platform	<b>P</b>	<b>12-pin connector</b>
	0	= None
	3	= IC (Not for OpenBus™)
	6	= LIN bus
	7	= CAN bus
	9	= CANopen
	A	= IO-Link
	X	= Special
Motor Type	<b>M</b>	
	A	= 12 V BDC
	B	= 24 V BDC
Endstop	<b>E</b>	
	0	= Power switch
	1	= Signal switch
	2	= Zero point
IP	<b>I</b>	
	A	= IP66 + IP69K
	B	= IP66 + IP69K + stainless steel screws
	C	= IP66 + Reinforced
	D	= IP66 + IP69K Reinforced + stainless steel screws
	T	= IECEx + ATEX (ATEX not for 12-pin connector)
	U	= IECEx + ATEX + stainless steel screws
	9	= Harsh environment + IP66/IP69K
Colour	<b>=</b>	
	=	= Dark grey
	-	= Black

## Ordering Example

**2 5 P P P X X X S S F F P M E I = B O R P C E F L P O X X X**



<b>Back fixture type</b>	<b>B</b>	<b>Zinc-coated steel</b>	<b>Stainless steel</b>
	1	= ø10.2 (0251011)	A = ø10.2 (0251015)
	2	= With bushings ø10.2	B = With bushings ø10.2
	3	= ø12.3 (0251010)	C = ø12.3 (0251014)
	4	= With bushings ø8.2	D = With bushings ø8.2
	5	= ø10.2 + nut (0251032)	F = ø10.2 + nut (0251034)
	6	= With bushings ø10.2 + nut	G = With bushings ø10.2 + nut
	7	= ø12.3 + nut (0251026)	H = ø12.3 + nut (0251033)
	8	= With bushings ø8.2 + nut	I = With bushings ø8.2 + nut
			M = Male adapter M12 (0251021)
			X = Special
<b>Back fixture orientation</b>	<b>O</b>		
	1	= 0 degrees	
	2	= 90 degrees	
<b>Piston rod eye</b>	<b>R</b>	<b>Zinc-coated steel</b>	<b>Stainless steel</b>
	1	= ø10.2 (0231033)	A = ø10.2 (0231096)
	2	= With bushings ø10.2	B = With bushings ø10.2
	3	= ø12.3 (0231016)	C = ø12.3 (0231095)
	4	= With bushings ø8.2	D = With bushings ø8.2
			K = Ball eye ø10 H7 (0351053)
			L = Ball eye ø12 H7 (0351035)
			F = Female adapter M8 (0251039)
			M = Male adapter M12 (231094)
			X = Special
<b>Plug type</b>	<b>P</b>		
	0	= None (Is to be chosen if cable and connectors are not wanted)	
	C	= Flying leads (Is to be chosen if connector is not wanted)	
	I	= Moulded Deutsch (DT4)	
	J	= Deutsch (DT4)	
	K	= AMP superseal	
	L	= Moulded AMP superseal	
	M	= M12 5P (Only IO-Link length: 0.3 m)	
	S	= SMPS (Only cable length: 0.3 and 1.5 m)	
	X	= Special	
<b>Cable</b>	<b>C</b>		
	0	= None	
	S	= Straight 0.75 m (8-core or 2-core when no feedback is needed)	
	T	= Straight 1.5 m (8-core or 2-core when no feedback is needed)	
	R	= Straight 5.0 m (8-core or 2-core when no feedback is needed)	
	U	= Straight 0.3 m (Only SMPS and IO-Link)	
	V	= Straight 10 m	
	Y	= Straight 1.5 m (11-core)	
	Z	= Straight 5 m (11-core)	
	X	= Special	

## Ordering Example

**2 5 P P P X X X S S F F P M E I = B O R P C E F L P O X X X**

<b>Endstop signal (Endstop reached in/out)</b>	<b>E</b>	<b>CAN / LIN / IO-Link</b>	<b>IC Advanced and I/O</b>
	0	= None	0 = None
		<b>Standard</b>	A = A_HIGH / A_HIGH
	0	= None	B = A_LOW / A_HIGH
	1	= Yes	C = A_HIGH / A_LOW
		<b>IC Basic</b>	D = A_LOW / A_LOW
	1	= Yes	E = LOW / A_HIGH
		<b>IC Parallel (Not for I/O)</b>	F = HIGH / A_HIGH
	1	= A_HIGH / A_HIGH	G = LOW / A_LOW
		<b>IC Parallel with Feedback</b>	H = HIGH / A_LOW
	X	= Special	J = A_HIGH / LOW
			K = A_LOW / LOW
			L = A_HIGH / HIGH
			M = A_LOW / HIGH
			N = LOW / LOW
			P = HIGH / LOW
			Q = LOW / HIGH
			R = HIGH / HIGH
			X = Special
<b>Feedback</b>	<b>F</b>		
		<b>CAN / LIN / IO-Link</b>	<b>IC Advanced and I/O</b>
	0	= None	0 = None
		<b>Standard</b>	A = 0 - 10 V
	0	= None	B = 0.5 - 4.5 V
	1	= 0 - 10 V	C = 4 - 20 mA
	2	= 0.5 - 4.5 V	D = 10 - 90% (Only IC Advanced)
	3	= 4 - 20 mA	E = 20 - 80% (Only IC Advanced)
	4	= 10 - 90%	G = 1 - 9 V
	5	= 20 - 80%	X = Special
	9	= Special	
		<b>IC Basic</b>	<b>IC Parallel (Not for I/O)</b>
	8	= None	Z = IC Parallel
			Y = Parallel with feedback
			X = Special
<b>Load type</b>	<b>L</b>		
	0	= Push/Pull	
	1	= Push	
	2	= Pull	
<b>Parallel mode</b>	<b>P</b>		
	0	= Non-critical Parallel	2-8 = Critical Parallel
<b>SW configuration</b>	<b>0</b>		
	0	= Standard configuration	
	X	= Special configuration	
<b>Built-in dimensions</b>	<b>XXX</b>	= BID (mm)	

## Dimensions



## Stroke tolerances

Platform options	Descriptions	Stroke tolerance	Example for 200 mm stroke
25030/060/090/120 XXXXXXX0	With built-in limit switches	+2 / -2 mm	198 to 202 mm
25200XXXXXX0	With built-in limit switches	+3 / -1 mm	199 to 203 mm
25XXXXXXXXXX3	Integrated Controller with built-in limit switches and zero point	+1 / -3 mm	197 to 201 mm
25200XXXXXXXX3	Integrated Controller with built-in limit switches and zero point	+2 / -2 mm	198 to 202 mm

## Built-in tolerances

Platform options	Descriptions	BID tolerance	Example for 200 mm BID
25XXXXXXXXXXXX	All variants	+2 / -2 mm	198 to 202 mm

## Built-in dimensions

The built-in dimension depends on the chosen safety option and stroke length(s).

			Piston rod types			
			1, 2, 3, 4, A, B, C, D	M / from the surface	K, L / to the centre of the hole	F / from the surface
Safety option	Stroke length	Spindle pitch	Min. built-in dimensions			
No safety option	20 - 49	3	168	165	179	158
No safety option	20 - 49	6, 9 or 12	160	157	171	150
No safety option	20 - 48	20	160	157	171	150
Safety nut for push	20 - 49	3	168	165	179	158
Safety nut for push	20 - 49	6, 9 or 12	160	157	171	150
Safety nut for pull	20 - 49	6, 9 or 12	172	169	183	162
<hr/>						
No safety option	50 - 200	3	118 + s	115 + s	129 + s	108 + s
No safety option	50 - 200	6, 9 or 12	110 + s	107 + s	121 + s	100 + s
No safety option	49 - 200	20	112 + s	109 + s	123 + s	102 + s
Safety nut for push	50 - 200	3	118 + s	115 + s	129 + s	108 + s
Safety nut for push	50 - 200	6, 9 or 12	110 + s	107 + s	121 + s	100 + s
Safety nut for pull	50 - 200	6, 9 or 12	122 + s	119 + s	133 + s	112 + s
<hr/>						
No safety option	201 - 400	3	138 + s	135 + s	149 + s	128 + s
No safety option	201 - 400	6, 9, 12 or 20	130 + s	127 + s	141 + s	120 + s
Safety nut for push	201 - 400	3	138 + s	135 + s	149 + s	128 + s
Safety nut for push	201 - 400	6, 9 or 12	130 + s	127 + s	141 + s	120 + s
Safety nut for pull	201 - 400	6, 9 or 12	142 + s	139 + s	153 + s	132 + s
<hr/>						
No safety option	401 - 500	3	158 + s	155 + s	169 + s	148 + s
No safety option	401 - 600	6, 9, 12 or 20	150 + s	147 + s	161 + s	140 + s
Safety nut for push	401 - 500	3	158 + s	155 + s	169 + s	148 + s
Safety nut for push	401 - 600	6, 9 or 12	150 + s	147 + s	161 + s	140 + s
Safety nut for pull	401 - 600	6, 9 or 12	162 + s	159 + s	173 + s	152 + s

Back fixture types 1, 2, 3, 4 and A, B, C, D


## Built-in dimensions

			Piston rod types			
			1, 2, 3, 4, A, B, C, D	M / from the surface	K, L / to the centre of the hole	F / from the surface
			<b>Min. built-in dimensions</b>			
Back fixture type M	Safety option	Stroke length	Spindle pitch			
	No safety option	20 - 49	3	155	152	166
	No safety option	20 - 49	6, 9 or 12	147	144	158
	No safety option	20 - 48	20	147	144	158
	Safety nut for push	20 - 49	3	155	152	166
	Safety nut for push	20 - 49	6, 9 or 12	147	144	158
	Safety nut for pull	20 - 49	6, 9 or 12	159	156	170
	No safety option	50 - 200	3	105 + s	102 + s	116 + s
	No safety option	50 - 200	6, 9 or 12	97 + s	94 + s	108 + s
	No safety option	49 - 200	20	99 + s	96 + s	110 + s
	Safety nut for push	50 - 200	3	105 + s	102 + s	116 + s
	Safety nut for push	50 - 200	6, 9 or 12	98 + s	94 + s	108 + s
	Safety nut for pull	50 - 200	6, 9 or 12	110 + s	106 + s	120 + s
	No safety option	201 - 400	3	125 + s	122 + s	136 + s
	No safety option	201 - 400	6, 9, 12 or 20	117 + s	114 + s	128 + s
	Safety nut for push	201 - 400	3	125 + s	122 + s	136 + s
	Safety nut for push	201 - 400	6, 9 or 12	117 + s	114 + s	128 + s
	Safety nut for pull	201 - 400	6, 9 or 12	129 + s	126 + s	140 + s
	No safety option	401 - 500	3	145 + s	142 + s	156 + s
	No safety option	401 - 600	6, 9, 12 or 20	137 + s	134 + s	148 + s
	Safety nut for push	401 - 500	3	145 + s	142 + s	156 + s
	Safety nut for push	401 - 600	6, 9, 12 or 20	137 + s	134 + s	148 + s
	Safety nut for pull	401 - 600	6, 9, 12 or 20	149 + s	146 + s	160 + s

## Built-in dimensions

			Piston rod types				
			1, 2, 3, 4, A, B, C, D	M / from the surface	K, L / to the centre of the hole	F / from the surface	
Back fixture types 5, 6, 7, 8 and F, G, H, I	Safety option	Stroke length	Spindle pitch	Min. built-in dimensions			
	No safety option	20 - 49	3	174	171	185	164
	No safety option	20 - 49	6, 9 or 12	166	163	177	156
	No safety option	20 - 48	20	166	163	177	156
	Safety nut for push	20 - 49	3	174	171	185	164
	Safety nut for push	20 - 49	6, 9 or 12	166	163	177	156
	Safety nut for pull	20 - 49	6, 9 or 12	178	175	189	168
	No safety option	50 - 200	3	124 + s	121 + s	135 + s	114 + s
	No safety option	50 - 200	6, 9 or 12	116 + s	113 + s	127 + s	106 + s
	No safety option	49 - 200	20	118 + s	115 + s	129 + s	108 + s
	Safety nut for push	50 - 200	3	124 + s	121 + s	135 + s	114 + s
	Safety nut for push	50 - 200	6, 9 or 12	116 + s	113 + s	127 + s	106 + s
	Safety nut for pull	50 - 200	6, 9 or 12	128 + s	125 + s	139 + s	118 + s
	No safety option	201 - 400	3	144 + s	141 + s	155 + s	134 + s
	No safety option	201 - 400	6, 9, 12 or 20	136 + s	133 + s	147 + s	126 + s
	Safety nut for push	201 - 400	3	144 + s	141 + s	155 + s	134 + s
	Safety nut for push	201 - 400	6, 9 or 12	136 + s	133 + s	147 + s	126 + s
	Safety nut for pull	201 - 400	6, 9 or 12	148 + s	145 + s	159 + s	138 + s
	No safety option	401 - 500	3	164 + s	161 + s	175 + s	154 + s
	No safety option	401 - 600	6, 9, 12 or 20	156 + s	153 + s	167 + s	146 + s
	Safety nut for push	401 - 500	3	164 + s	161 + s	175 + s	154 + s
	Safety nut for push	401 - 600	6, 9, 12 or 20	156 + s	153 + s	167 + s	146 + s
	Safety nut for pull	401 - 600	6, 9, 12 or 20	168 + s	165 + s	179 + s	158 + s

## Built-in dimensions





## Piston rod eyes

Option "1" and "A"

Piston 0231033, zinc-coated steel



Piston 0231096, stainless steel AISI 304



Option "2" and "B"



Piston 0231016 with bushings, zinc-coated steel

Piston 0231095 with bushings, stainless steel AISI 304





## Piston rod eyes

Option "3" and "C"  
 Piston 0231016, zinc-coated steel  
 Piston 0231095, stainless steel AISI 304





Option "4" and "D"  
 Piston 0231033 with bushings, zinc-coated steel  
 Piston 0231096 with bushings, stainless steel AISI 304







## Piston rod eyes



Option "K"  
Piston 0351053, stainless steel AISI 304



Option "L"  
Piston 0351035, stainless steel AISI 304



Option "M"  
Piston 0231094, stainless steel AISI 304




The piston rod eye is only allowed to turn 0-180 degrees anti-clockwise.

## Back fixtures


Option "1" and "A"

LINAK P/N: 0251011 without bushings, zinc-coated steel  
0251015 without bushings, stainless steel AISI 304




Option "2" and "B"

LINAK P/N: 0251010 with bushings, zinc-coated steel  
0251014 with bushings, stainless steel AISI 304



Option "3" and "C"


LINAK P/N: 0251010 without bushings, zinc-coated steel  
0251014 without bushings, stainless steel AISI 304



## Back fixtures


Option "7" and "H"

LINAK P/N 0251026 without bushings, zinc-coated steel  
0251033 without bushings, stainless steel AISI 304




Option "8" and "I"

LINAK P/N 0251032 with bushings, zinc-coated steel  
0251034 with bushings, stainless steel AISI 304




Option "M"


LINAK P/N: 0251021, stainless steel AISI 303



## Back fixture orientation





Option 1 = 0°



Option 2 = 90°

## Mounting of cables



When changing the cables on a LINAK® actuator, it is important that this is done carefully, in order to protect the plugs and pins. Before the new cable is mounted, we recommend that the socket is greased with vaseline, to keep the high IP protection and ensure an easy mounting. Please be sure that the plug is in the right location and fully pressed in before the cable lid is mounted.

Please note that if the cables are mounted and dismounted more than 3 times the plugs can be damaged. Therefore, we recommend that such cables are discarded and replaced.


Also note that the cables should not be used for carrying the actuator.

We recommend to take some precaution and design the wire connection in a way, where the cable end is kept inside a closed, protected area to guarantee the high IP protection.



NOT valid for ATEX cables, please refer to the ATEX section for correct cable mounting on ATEX actuators.

## Cable dimensions



Wire without insulation:

Brown:	1.0 mm <sup>2</sup>	18 AWG*
Blue:	1.0 mm <sup>2</sup>	18 AWG
Violet:	1.0 mm <sup>2</sup>	18 AWG
Black:	1.0 mm <sup>2</sup>	18 AWG
Red:	1.0 mm <sup>2</sup>	18 AWG
Yellow:	1.0 mm <sup>2</sup>	18 AWG
Green:	1.0 mm <sup>2</sup>	18 AWG
White:	1.0 mm <sup>2</sup>	18 AWG

Wire with insulation:

Brown:	1.8 mm <sup>2</sup>
Blue:	1.8 mm <sup>2</sup>
Violet:	1.8 mm <sup>2</sup>
Black:	1.8 mm <sup>2</sup>
Red:	1.8 mm <sup>2</sup>
Yellow:	1.8 mm <sup>2</sup>
Green:	1.8 mm <sup>2</sup>
White:	1.8 mm <sup>2</sup>


## Standard cable item numbers (included in new actuator)

Connector	C		J/K		I/L		
Ordering no.	LA25 cable item no.	Length (mm)		Length (mm)		Length (mm)	
S	0147001 - 850	CS	810	JS/KS	785	IS/LS	740
T	0147001 - 1600	CT	1560	JT/KT	1535	IT/LT	1490
R	0147001 - 5100	CR	4960	JR/KR	4935	IR/LR	4890
V	0147001 - 10100	CV	10060	JV/KV	10035	IV/LV	9990

The LA25 standard cable is a UV-resistant PVC cable.

\*AWG: American Wire Gauge

## Cable dimensions



## Standard cable item numbers (included in new actuator)

LA25 cable item no.	Length
0257057 - 0850	850 ± 30
0257057 - 1600	1600 ± 30
0257057 - 2000	2000 ± 40
0257057 - 5100	5100 ± 50
0257057 - 10100	10100 ± 100
0257057 - 15100	15100 ± 100

## Electrical installation

### For Standard actuators:

- To ensure maximum self-locking ability, please be sure that the motor is shorted when stopped. When using soft stop on a DC-motor, a short peak of higher voltage will be sent back towards the power supply. It is important when selecting the power supply that it does not turn off the output, when this backwards load dump occurs. The power supply must be monitored externally and cut off in case of current overload.

### For IC actuators:

- As long as the actuator is powered, actuators with Integrated Controller ensure that the motor is shorted when stopped.

## Environmental tests – Climatic

Test	Specification	Comment	TRD number
Cold test	EN60068-2-1 (Ab)	Storage at low temperature: Temperature: - 40°C Duration: 72 h Actuator is not connected/operated Tested at room temperature	TRD5675
		Storage at low temperature: Temperature: -55°C Duration: 24 h Actuator is not connected Tested at room temperature	TRD5675
	EN60068-2-1 (Ad)	Operating at low temperature: Temperature: -40°C Duration: 4 h Tested at room temperature within 5 minutes overload	
Dry heat	EN60068-2-2 (Bb)	Storage at high temperature: Temperature: +85°C Duration: 72 h Actuator is not connected/operated Tested at room temperature	TRD5675
	EN60068-2-2 (Bb)	Storage at low temperature: Temperature: +105°C Duration: 24 h Actuator operated at high temperature	TRD5675
Damp heat	EN60068-2-30 (Db)	Damp heat, Cyclic: Relative humidity: 93-98% High temperature: +55°C in 12 hours Low temperature: +25°C in 12 hours Duration: 21 cycles * 24 hours Actuator is operated during test	TRD5677
Salt mist	EN ISO 9227	Dynamic salt spray test: Salt solution: 5% sodium chloride (NaCl) Temperature: 35 ± 2°C Duration: 500 h Actuator is operated	TRD5678
Thermal shock		Dunk test: Actuator is heated to +85°C for 4 h and submerged into a 0°C cold salt-water-detergent solution for 2 h Followed by 18 h dry time Duration: 5 cycles	TRD5679

Degrees of protection	EN60529 - IP66	IP6X - Dust: Dust-tight - no ingress of dust Actuator is not activated	TRD5680
	EN60529 - IP66	IPX6 - Water: Ingress of water in quantities causing harmful effects is not allowed Duration: 100 litres pr. minute for 3 minutes Actuator is not activated	TRD5682
	DIN40050 - IP69K	IPX9K: High pressure cleaner Temperature: +80°C Water pressure: 80-100 bar Water flow: 14-16 l/min Duration: 30 seconds each at 4 different angles: 0°, 30°, 60° and 90° Actuator is not activated Ingress of water in quantities causing harmful effects is not allowed	TRD5680
Rain		Dynamic rain test: Actuators exposed to continuous rain Actuators operated and sideloaded with 5 N Duration: 10.000 cycles and 240 h	TRD5681

## Environmental tests – Mechanical

Test	Specification	Comment	TRD number
Mechanical shock (handling) - drop test		3 drops on 6 faces onto a concrete floor Drop height: 500 mm on all surfaces	TRD5683
Mechanical shock operational		Peak Pulse Amplitude: 50 G Pulse Duration: 11 ms Number of pulses: 18 total - 3 in each direction for all three axes	TRD5684
		Peak Pulse Amplitude: 30 G Pulse Duration: 18 ms Number of pulses: 18 total - 3 in each direction for all three axes	TRD5684
		Peak Pulse Amplitude: 25 G Pulse Duration: 6 ms Number of pulses: 6000 total- 1000 in each direction for all three axes	TRD5684
Vibration random		Random vibration: From 18 Hz - 0,025 G to 1000 Hz - 0,015 G  Duration: 2 h/axis UM-32-30-003	TRD5684

## Environmental tests - Electrical

Standard	Specification	FOCUS ON
2004/104/EC	Automotive EMC Directive 2004/104/EC on electrical and electronic car components	<ul style="list-style-type: none"> <li>• VEHICLES AND MOBILITY</li> </ul>
EN/IEC 60204-1: 2006 +A1: 2009	Safety of machinery - Electrical equipment of machines - Part 1: General requirements	<ul style="list-style-type: none"> <li>• INDUSTRIAL AUTOMATION</li> </ul>
EN/IEC 60204 -32: 2008	Safety of machinery - Electrical equipment of machines - Part 32: Requirements for hoisting machines	<ul style="list-style-type: none"> <li>• INDUSTRIAL AUTOMATION</li> <li>• PLATFORMS AND LIFTS</li> </ul>
EN/IEC 61000-6-1: 2007	Electromagnetic compatibility (EMC) - Part 6-1: Generic standards - Immunity for industrial environments	<ul style="list-style-type: none"> <li>• INDUSTRIAL AUTOMATION</li> </ul>
EN/IEC 61000-6-2: 2005	Electromagnetic compatibility (EMC) - Part 6-2: Generic standards - Immunity for industrial environments	<ul style="list-style-type: none"> <li>• INDUSTRIAL AUTOMATION</li> </ul>
EN/IEC 61000-6-3: 2007 + A1:2011	Electromagnetic compatibility (EMC) - Part 6-3: Generic standards - Emission standard for residential, commercial and light-industrial environments	<ul style="list-style-type: none"> <li>• INDUSTRIAL AUTOMATION</li> </ul>
EN/IEC 61000-6-4: 2007 + A1:2011	Electromagnetic compatibility (EMC) - Part 6: Generic standards - Section 4: Emission standard for industrial environments	<ul style="list-style-type: none"> <li>• INDUSTRIAL AUTOMATION</li> </ul>
EN 13309: 2010	Construction machinery	<ul style="list-style-type: none"> <li>• CONSTRUCTION</li> </ul>
EN/ISO 13766: 2006	Earth-moving machinery - Electromagnetic compatibility	<ul style="list-style-type: none"> <li>• CONSTRUCTION</li> </ul>
EN/ISO 14982: 2009	Agricultural and forestry machines - Electromagnetic compatibility	<ul style="list-style-type: none"> <li>• MOBILE AGRICULTURE</li> <li>• OUTDOOR POWER EQUIPMENT</li> </ul>
EU recreational crafts directive 94/25/EC		
IECEx / ATEX (Ex)	EN60079-0:2012 EN60079-31:2014 This Ex certification allows the actuator to be mounted in Ex dust areas: II 2D Ex tb IIIC T135°C Db Tamb -25°C to +65°C	



All electrical and radiated emission tests (EMC) have been conducted.

## Non-complying standards

Standard	Explanation
IEC 60601-1	Please note that this product cannot be approved according to the medical electrical equipment standard. Due to the combination of the aluminium cast housing and the embedded PCB, we do not fulfil the regulations according to leakage current.

**FACTORIES**

Denmark - Headquarters

LINAK A/S

Phone: +45 73 15 15 15

Fax: +45 74 45 80 48

Fax (Sales): +45 73 15 16 13

Web: www.linak.com

China

LINAK (Shenzhen) Actuator Systems, Ltd.

Phone: +86 755 8610 6656

Phone: +86 755 8610 6990

Web: www.linak.cn

Slovakia

LINAK Slovakia s.r.o.

Phone: +421 51 7563 444

Web: www.linak.sk

Thailand

LINAK APAC Ltd.

Phone: +66 33 265 400

Web: www.linak.com

USA

LINAK U.S. Inc.

Americas Headquarters

Phone: +1 502 253 5595

Fax: +1 502 253 5596

Web: www.linak-us.com

www.linak-latinamerica.com

**SUBSIDIARIES**

Australia

LINAK Australia Pty. Ltd.

Phone: +61 3 8796 9777

Fax: +61 3 8796 9778

E-mail: sales@linak.com.au

Web: www.linak.com.au

Austria

LINAK Zweigniederlassung - Österreich (Wien)

Phone: +43 (1) 890 7446

Fax: +43 (1) 890 744615

E-mail: info@linak.de

Web: www.linak.at - www.linak.hu

Belgium

LINAK Actuator-Systems NV/SA

(Belgium &amp; Luxembourg)

Phone: +32 (0)9 230 01 09

E-mail: beinfo@linak.be

Web: www.linak.be - www.fr.linak.be

Brazil

LINAK Do Brasil Comércio De Atuadores Ltda.

Phone: +55 (11) 2832 7070

Fax: +55 (11) 2832 7060

E-mail: info@linak.com.br

Web: www.linak.com.br

Canada

LINAK Canada Inc.

Phone: +1 502 253 5595

Fax: +1 416 255 7720

E-mail: info@linak.ca

Web: www.linak-us.com

Czech Republic

LINAK C&amp;S s.r.o.

Phone: +42 058 174 1814

Fax: +42 058 170 2452

E-mail: info@linak.cz

Web: www.linak.cz - www.linak.sk

Denmark - International

LINAK International

Phone: +45 73 15 15 15

E-mail: info@linak.com

Web: www.linak.com

Denmark - Sales

LINAK Denmark A/S

Phone: +45 86 80 36 11

Fax: +45 86 82 90 51

E-mail: linak@linak-silkeborg.dk

Web: www.linak.dk

Finland

LINAK OY

Phone: +358 10 841 8700

E-mail: linak@linak.fi

Web: www.linak.fi

France

LINAK France E.U.R.L

Phone: +33 (0) 2 41 36 34 34

Fax: +33 (0) 2 41 36 35 00

E-mail: linak@linak.fr

Web: www.linak.fr

Germany

LINAK GmbH

Phone: +49 6043 9655 0

Fax: +49 6043 9655 60

E-mail: info@linak.de

Web: www.linak.de

India

LINAK A/S India Liaison Office

Phone: +91 120 4531797

Fax: +91 120 4786428

E-mail: info@linak.in

Web: www.linak.in

Ireland

LINAK UK Limited (Ireland)

Phone: +44 (0)121 544 2211

Fax: +44 (0)121 544 2552

+44 (0)796 855 1606 (UK Mobile)

+35 387 634 6554 (Rep.of Ireland Mobile)

E-mail: sales@linak.co.uk

Web: www.linak.co.uk

Italy

LINAK ITALIA S.r.l.

Phone: +39 02 48 46 33 66

Fax: +39 02 48 46 82 52

E-mail: info@linak.it

Web: www.linak.it

Japan

LINAK K.K.

Phone: +81-45-533-0802

Fax: +81-45-533-0803

E-mail: linak@linak.jp

Web: www.linak.jp

Malaysia

LINAK Actuators Sdn. Bhd.

Phone: +60 4 210 6500

Fax: +60 4 226 8901

E-mail: info@linak-asia.com

Web: www.linak.my

Netherlands

LINAK Actuator-Systems B.V.

Phone: +31 76 5 42 44 40 /

+31 76 200 11 10

E-mail: info@linak.nl

Web: www.linak.nl

New Zealand

LINAK New Zealand Ltd

Phone: +64 9580 2071

Fax: +64 9580 2072

E-mail: nsales@linak.com.au

Web: www.linak.com.au

Norway

LINAK Norge AS

Phone: +47 32 82 90 90

E-mail: info@linak.no

Web: www.linak.no

Poland

LINAK Polska

LINAK Denmark A/S (Spółka Akcyjna)

Phone: +48 22 295 09 70 /

+48 22 295 09 71

E-mail: info@linak.pl

Web: www.linak.pl

Republic of Korea

LINAK Korea Ltd.

Phone: +82 2 6231 1515

Fax: +82 2 6231 1516

E-mail: info@linak.kr

Web: www.linak.kr

Slovakia

LINAK Slovakia S.R.O.

Phone: +421 51 7563 444

Web: www.linak.sk

Spain

LINAK Actuadores, S.L.u

Phone: +34 93 588 27 77

Fax: +34 93 588 27 85

E-mail: esma@linak.es

Web: www.linak.es

Sweden

LINAK Scandinavia AB

Phone: +46 8 732 20 00

Fax: +46 8 732 20 50

E-mail: info@linak.se

Web: www.linak.se

Switzerland

LINAK AG

Phone: +41 43 388 31 88

Fax: +41 43 388 31 87

E-mail: info@linak.ch

Web: www.linak.ch - www.fr.linak.ch

www.it.linak.ch

Taiwan

LINAK (Shenzhen) Actuator systems Ltd.

Taiwan Representative office

Phone: +886 2 272 90068

Fax: +886 2 272 90096

E-mail: sales@linak.com.tw

Web: www.linak.com.tw

Turkey

LINAK İth. Ihr. San. ve Tic. A.Ş.

Phone: +90 312 4726338

Fax: +90 312 4726635

E-mail: info@linak.com.tr

Web: www.linak.com.tr

United Kingdom

LINAK UK Limited

Phone: +44 (0)121 544 2211

Fax: +44 (0)121 544 2552

E-mail: sales@linak.co.uk

Web: www.linak.co.uk

**DISTRIBUTORS**

Argentina

Novotec Argentina SRL

Phone: 011-4303-8989 / 8900

Fax: 011-4032-0184

E-mail: info@novotecargentina.com

Web: www.novotecargentina.com

Colombia

MEM Ltda

Phone: +57 (1) 334-7666

Fax: +57 (1) 282-1684

E-mail: servicioalcliente@memltda.com.co

Web: www.mem.net.co

India

Mechtronics Control Equipments India Pvt Ltd

Phone: +91-44-28558484, 85

E-mail: bala@mechtronicscontrol.com

Web: www.mechtronicscontrol.com

Indonesia

PT. Himalaya Everest Jaya

Phone: +6 221 544 8956 /+6 221 544 8965

Fax: +6 221 619 1925

Fax (Sales): +6 221 619 4658

E-mail: hejplastic-div@centrin.net.id

Web: www.hej.co.id

Israel

NetivTech LTD

Phone: +972 55-2266-535

Fax: +972 2-9900-560

Email: info@NetivTech.com

Web: www.netivtech.com

Singapore

Servo Dynamics Pte Ltd

Phone: +65 6844 0288

Fax: +65 6844 0070

E-mail: servodynamics@servo.com.sg

South Africa

Industrial Specialised Applications CC

Phone: +27 011 466 0346

E-mail: garth@isagroup.co.za

Web: www.isaza.co.za

United Arab Emirates

Mechtronics

Phone: +971 4 267 4311

Fax: +971 4 267 4312

E-mail: mechtron@emirates.net.ae

**Terms of use**

LINAK® takes great care in providing accurate and up-to-date information on its products. However, the user is responsible for determining the suitability of LINAK products for a specific application. Due to continual development, LINAK products are subject to frequent modifications and changes. LINAK reserves the rights to conduct modifications, updates, and changes without any prior notice. For the same reason, LINAK cannot guarantee the correctness and actual status of imprinted information on its products.

LINAK uses its best efforts to fulfil orders. However, for the reasons mentioned above, LINAK cannot guarantee availability of any particular product at any given time. LINAK reserves the right to discontinue the sale of any product displayed on its website or listed in its catalogues or in other written material created and produced by LINAK, LINAK subsidiaries, or LINAK affiliates. All sales are subject to the 'Standard Terms of Sale and Delivery for LINAK A/S' available on LINAK websites. LINAK and the LINAK logotype are registered trademarks of LINAK A/S. All rights reserved.